

# Brewer's Best<sup>®</sup> Electric Brew Heater



## For Mashing, Sparge, and Boiling

- Safely boils liquids indoors
- Built-in thermostat for temperature control
- GFCI power cord standard for safe use

For any questions or concerns visit [www.brewersbestkits.com](http://www.brewersbestkits.com)

## How to use your Brew Heater

### Read carefully before operating:

- Do not touch metal heating element while hot.
- Do not immerse unit housing, cord, or plug in liquid.
- Unplug unit when not in use and before removing from liquid.
- Never disassemble the Brewer's Best<sup>®</sup> Brew Heater.
- Submerge the lower "L" section of the heating element when in use.
- The Brewer's Best<sup>®</sup> Brew Heater can be used to mash or sparge in plastic containers.
- Do not use override boil switch in plastic containers.
- Always allow heating element to cool completely before touching.
- This product is intended to heat liquids only.
- Engage the boil switch only when full power is needed.

### Directions

1. To use the Brewer's Best<sup>®</sup> Brew Heater, first inspect the unit to look for any damages or possible entry points for liquid.
2. Immerse the lower "L" section of the Brewer's Best<sup>®</sup> Brew Heater (9" Hot Zone) into the liquid to be heated. The heater can be attached to the side of any stainless steel brew pot for hands-free heating.
3. For mashing and sparge, the unit's thermostat can be set from 110°-190°F. Adjust the thermostat by turning the knob clockwise to raise temperature; counterclockwise to lower temperature.
4. Temperature readings on unit are approximate. You must use an external thermostat to control the liquid being heated.
5. To boil, turn the boil switch to the on position.
6. Refer to the diagram on the Brewer's Best<sup>®</sup> Brew Heater for switch positioning and temperature range chart.



Distributed by LD Carlson Co.  
Kent, OH 44240  
[www.ldcarlson.com](http://www.ldcarlson.com)



# How to use your Brew Heater

**Read carefully before operating:**

- Do not touch metal heating element while hot.
- Do not immerse unit housing, cord, or plug in liquid.
- Unplug unit when not in use and before removing from liquid.
- Never disassemble the Brewer's Best® Brew Heater.
- Submerge the lower "L" section of the heating element when in use.
- The Brewer's Best® Brew Heater can be used to mash or sparge in plastic containers.
- Do not use override boil switch in plastic containers.
- Always allow heating element to cool completely before touching.
- This product is intended to heat liquids only.

## Directions

1. To use the Brewer's Best® Brew Heater, first inspect the unit to look for any damages or possible entry points for liquid.
2. Immerse the lower "L" section of the Brewer's Best® Brew Heater (9" Hot Zone) into the liquid to be heated. The heater can be attached to the side of any stainless steel brew pot for hands-free heating.
3. For mashing and sparge, the unit's thermostat can be set from 110°-190°F. Adjust the thermostat by turning the knob clockwise to raise temperature; counterclockwise to lower temperature.
4. Temperature readings on unit are approximate. You must use an external thermostat to control the liquid being heated.
5. To boil, turn the boil switch to the on position.
6. Refer to the diagram on the Brewer's Best® Brew Heater for switch positioning and temperature range chart.

Distributed by LD Carlson Co.  
Kent, OH 44240  
www.ldcarlson.com



# How to use your Brew Heater

**Read carefully before operating:**

- Do not touch metal heating element while hot.
- Do not immerse unit housing, cord, or plug in liquid.
- Unplug unit when not in use and before removing from liquid.
- Never disassemble the Brewer's Best® Brew Heater.
- Submerge the lower "L" section of the heating element when in use.
- The Brewer's Best® Brew Heater can be used to mash or sparge in plastic containers.
- Do not use override boil switch in plastic containers.
- Always allow heating element to cool completely before touching.
- This product is intended to heat liquids only.

## Directions

1. To use the Brewer's Best® Brew Heater, first inspect the unit to look for any damages or possible entry points for liquid.
2. Immerse the lower "L" section of the Brewer's Best® Brew Heater (9" Hot Zone) into the liquid to be heated. The heater can be attached to the side of any stainless steel brew pot for hands-free heating.
3. For mashing and sparge, the unit's thermostat can be set from 110°-190°F. Adjust the thermostat by turning the knob clockwise to raise temperature; counterclockwise to lower temperature.
4. Temperature readings on unit are approximate. You must use an external thermostat to control the liquid being heated.
5. To boil, turn the boil switch to the on position.
6. Refer to the diagram on the Brewer's Best® Brew Heater for switch positioning and temperature range chart.

Distributed by LD Carlson Co.  
Kent, OH 44240  
www.ldcarlson.com

